

e Eplan Platform 2.9 cheat sheet

General

Space	Define window (selection area)
Tab	Jump to the element points of the selected elements
Tab or Ctrl + Wheel up and wheel down	Insert symbol: change variant
Tab or Ctrl + Wheel up and wheel down	Insert macro: Change variant
A	Change handle in 3D mounting layout navigator
B	Create macro
D	Duplicate window (selection area)
E	Insert ellipse
F	Search function: Jump to counterpiece
G	Group elements
H	Adopt length of mounting rail
I	Turn display of insertion points on/off
J	Centered mounting rail placement
K	Insert circle
L	Insert polyline
M	Insert window macro / symbol macro
N	Jump to next function (when placing and assigning functions)
O	Move base point on/off
P	Coordinate input
Q	Quick snap on / off
R	Insert rectangle
S	Set increment
T	Insert text
U	Show / hide invisible elements
V	Move
X	Activate orthogonal function
X then X	Insert macro: Set cursor to horizontal start position
Y then Y	Activate orthogonal function
Y	Insert macro: Set cursor to vertical start position

Z	Open zoom
< or >	Activate / deactivate orthogonal function in the horizontal / vertical direction, deactivate enabled orthogonal function
F1 or Ctrl + F1	Call up context help
F2	Call processing mode (in specific displays in tables, such as the Multilingual input dialog)
F2	Direct editing (temporary)
F3	Insert angle (down, right)
F4	Insert angle (down, left)
F5	Update view ("Redraw")
Ctrl	(hold then input) Update view ("Redraw")
F6	Insert angle (up, left)
F7	Insert T-node (down)
F8	Insert T-node (up)
F9	Insert T-node (right)
F10	Insert T-node (left)
F12	Open / close page navigator
Insert	Insert symbol
Del	Delete the contents of a window (selection area)
Home	Move cursor to left edge of screen
End	Move cursor to right edge of screen
Page Down	Next page
Page Up	Previous page
Arrow keys	Jump in grid
Esc	Cancel action
Shift + Alt + Arrow keys	Jump to element points lying at the same height / in the same path
Shift + F3	Insert device connection points
Shift + F4	Insert interruption points
Shift + F5	Insert cable definition
Shift + F6	Insert shield
Shift + F7	Insert connection definition point
Shift + F8	Insert jumper (double junction connection)
Shift + F11	Insert black box
Shift + Left arrow	Move image section left
Shift + <	Activate / deactivate orthogonal

function	
Shift + Right arrow	Move image section right
Shift + Up arrow	Move image section up
Shift + Down arrow	Move image section down
Shift + R	Enter relative coordinates
Shift + Ctrl + Arrow keys	Jump to element points
Shift + Tab	Insert macro: Change representation type
Ctrl + End	Jump to lower edge of screen
Ctrl + Home	Jump to upper edge of screen
Ctrl + Enter	Insert line break
Ctrl + Left click or Ctrl + Space	Jump from cross-reference to counterpiece
Ctrl + Shift + Left click	Jump from cross-reference to counterpiece and open a new window of the graphical editor at the same time
Ctrl + Shift	(then blank) Jump from cross-reference to counterpiece and open a new window of the graphical editor at the same time
Ctrl + A	Select all
Ctrl + B	Move property texts
Ctrl + C	Copy elements into the EPLAN clipboard
Ctrl + D	Edit object properties
Ctrl + E	Generate reports
Ctrl + F	Call up search function
Ctrl + G	Insert arc through center
Ctrl + I	Insert element into search results list
Ctrl + J	Go to (graphic)
Ctrl + K	Generate macros from a macro project
Ctrl + L	Use existing PLC connection points blockwise
Ctrl + M	Select a page
Ctrl + N	Create a page
Ctrl + O	Address PLC
Ctrl + P	Print a project
Ctrl + Q	Open / close Edit in table
Ctrl + R	Rotate graphic
Ctrl + S	Search function: Synchronize selection
Ctrl + T	Insert a path function text
Ctrl + V	Insert elements from the EPLAN clipboard
Ctrl + W	Set options for placement of parts in 3D mounting layout navigator
Ctrl + X or Shift + Del	Cut elements and copy into the EPLAN clipboard
Ctrl + Y	Redo last step
Ctrl + Z or Alt + Backspace	Undo last step
Ctrl + F2	Insert line
Ctrl + F4	Close graphical editor
Ctrl + F5	Create window macro / symbol macro
Ctrl + F6	Switch between the windows such as graphical editors, navigators etc., that are docked as a tab
Ctrl + F7	Switch between the tabs for navigators, editors, etc., that are arranged on top of each other in a dockable windows
Ctrl + F10	Create page macro
Ctrl + F11	Add structure boxes
Ctrl + F12	Switch between open windows, like the graphical editor, navigators, etc.
Ctrl + <	Update reports
Ctrl + Arrow keys	Jump left to the next insertion point
Ctrl + Arrow keys	Jump right to the next insertion point
Ctrl + Arrow keys	Jump up to the next insertion point
Ctrl + Arrow keys	Jump down to the next insertion point
Ctrl + Shift + A	Insert linear dimension
Ctrl + Shift + D	Global editing: Edit data from report
Ctrl + Shift + E	Open / close message management
Ctrl + Shift + F	Search function: Jump to next entry
Ctrl + Shift + M	Open / close 2D panel layout navigator

Ctrl + Shift + P	Check project
Ctrl + Shift + R	Modify rotation angle of 3D macro
Ctrl + Shift + U	Interrupt connections
Ctrl + Shift + V	Search function: Jump to previous entry
Ctrl + Shift + F6	Grid display on/off
Ctrl + Shift + <	Generate project reports
Alt + 3	Show whole page
Alt + F4	Exit EPLAN
Alt + Page Down	Search function: Jump to next cross-referenced function, forward
Alt + Page Up	Search function: Jump to next cross-referenced function, backward
Alt + Insert	Insert device
Alt + Del	Delete placement
Alt + Left arrow	Jump to left insertion point at the same height
Alt + Right arrow	Jump to right insertion point at the same height
Alt + Up arrow	Jump to top insertion point in the same path
Alt + Down arrow	Jump to bottom insertion point in the same path
Alt + Home	Jump to nearest element point; this can also be the end point of an element
Ctrl + Alt + A	Edit workspace
Ctrl + Alt + T	3D viewpoint top
Ctrl + Alt + D	3D viewpoint bottom
Ctrl + Alt + L	3D viewpoint left
Ctrl + Alt + R	3D viewpoint right
Ctrl + Alt + F	3D viewpoint front
Ctrl + Alt + B	3D viewpoint back
Ctrl + Alt + 1	3D viewpoint SW Isometric
Ctrl + Alt + 2	3D viewpoint SE Isometric
Ctrl + Alt + 3	3D viewpoint NE Isometric
Ctrl + Alt + 4	3D viewpoint NW Isometric

Source: Eplan

Last modification: 2/26/2021 10:59:06 AM

More information: defkey.com/eplan-2-9-shortcuts